

Electronic Components Part Numbers Stock at iiiC.CC

mailto:manager@iiic.cc

2SK2051-L 5000 05+ FUJI TO-252
2SK2051-S 5000 05+ FUJI TO-252
2SK2071-01L 5000 05+ FUJI TO-252
2SK2071-01S 5000 05+ FUJI TO-252
2SK2072-01L 5000 05+ FUJI TO-252
2SK2072-01S 5000 05+ FUJI TO-252
2SK2099 1000 05+ FUJI SOT-252
2SK2099-01L 5000 05+ FUJI TO-252
2SK2099-01S 5000 05+ FUJI TO-252
2SK2213-01S 5000 05+ FUJI TO-252
2SK2215-01L 5000 05+ FUJI TO-252
2SK2215-01S 5000 05+ FUJI TO-252
2SK2226-01L 5000 05+ FUJI TO-252
2SK2226-01S 5000 05+ FUJI TO-252
2SK2248-01L 5000 05+ FUJI TO-252
2SK2248-01S 5000 05+ FUJI TO-252
2SK2249-01L 5000 05+ FUJI TO-252
2SK2249-01S 5000 05+ FUJI TO-252
2SK2250-01L 5000 05+ FUJI TO-252
2SK2250-01S 5000 05+ FUJI TO-252
2SK2252-01S 5000 05+ FUJI TO-252
2SK2292-01L 5000 05+ FUJI TO-252
2SK2292-01S 5000 05+ FUJI TO-252
2SK2446 5000 05+ FUJI TO-252
2SK2446-L 5000 05+ FUJI TO-252
2SK2446-S 5000 05+ FUJI TO-252
2SK2516-01L 5000 05+ FUJI TO-252
2SK2516-01S 5000 05+ FUJI TO-252
2SK2517-01L 5000 05+ FUJI TO-252
2SK2517-01S 5000 05+ FUJI TO-252
2SK2648 300 03+ FUJI N/A
2SK2754-01L 5000 05+ FUJI TO-252
2SK2754-01S 5000 05+ FUJI TO-252
2SK2765 500 03+ FUJI N/A
2SK2768-01L 5000 05+ FUJI TO-252
2SK2768-01S 5000 05+ FUJI TO-252
2SK2850 300 03+ FUJI N/A
2SK2870-01L 5000 05+ FUJI TO-252
2SK2870-01S 5000 05+ FUJI TO-252
2SK2874 5000 05+ FUJI TO-252
2SK2874-01L 5000 05+ FUJI TO-252
2SK2874-01S 5000 05+ FUJI TO-252
2SK2901-01L 5000 05+ FUJI TO-252
2SK2901-01S 5000 05+ FUJI TO-252
2SK2908-01L 5000 05+ FUJI TO-252
2SK2908-01S 5000 05+ FUJI TO-252
2SK3272-01S 5000 05+ FUJI TO-252
2SK3272-01S-TE24R 900 04+ FUJI N/A
2SK3580 10000 03+ FUJI TO-220
2SK724 500 03+ FUJI N/A

2SK902 1080 03+ FUJI TO-3P
2SK903 5000 03+ FUJI TO-3P
2SK955 800 03+ FUJI N/A
3R3TI20E-080 100 2003+ FUJI 20A/800V/SCR+DIODE/6U
3R3TI30E-080 150 2003+ FUJI 30A/800V/SCR+DIODE/6U
3R3TI60E-080 120 2003+ FUJI 60A/800V/SCR+DIODE/6U
4R3TI20Y-080 55 2003+ FUJI 20A/800V/SCR+DIODE/6U
4R3TI30Y-080 60 2003+ FUJI 30A/800V/SCR+DIODE/6U
4R3TI60Y-080 80 2003+ FUJI 60A/800V/SCR+DIODE/6U
6D100A-050ELX 55 2003+ FUJI 100A/500V/GTR/6U
6D50A-120ELX 30 2003+ FUJI 50A/1200V/GTR/6U
6D75A-050ELX 50 2003+ FUJI 75A/500V/GTR/6U
6DI100M-050 262 2003+ FUJI 100A/500V/GTR/6U
6DI100MA-050 100 2003+ FUJI 100A/500V/GTR/6U/LONG
6DI100MB-050 150 2003+ FUJI 100A/500V/GTR/6U
6DI10A-050 242 2003+ FUJI 10A/500V/GTR/6U
6DI10A-050B 50 2003+ FUJI 10A/500V/GTR/6U
6DI10MS-050 243 2003+ FUJI 10A/500V/GTR/6U
6DI120C-060 100 2003+ FUJI 120A/600V/GTR/6U
6DI120D-060 100 2003+ FUJI 120A/600V/GTR/6U
6DI150A-050 100 2003+ FUJI 150A/550V/GTR/6U/LONG
6DI150AH-060 100 2003+ FUJI 150A/600V/GTR/6U
6DI15A-050 244 2003+ FUJI 15A/500V/GTR/6U
6DI15M-120 50 2003+ FUJI 15A/1200V/GTR/6U
6DI15MS-050 245 2003+ FUJI 15A/500V/GTR/6U
6DI20D-040 100 2003+ FUJI 20A/400V/GTR/6U
6DI20S-050D 80 2003+ FUJI 20A/500V/GTR/6U
6DI30A-050 249 2003+ FUJI 30A/500V/GTR/6U
6DI30B-050 251 2003+ FUJI 30A/500V/GTR/6U
6DI30MA-050 253 2003+ FUJI 30A/500V/GTR/6U
6DI50A-050 250 2003+ FUJI 50A/500V/GTR/6U
6DI50A-055 272 2003+ FUJI 50A/550V/GTR/6U
6DI50A-060 150 2003+ FUJI 50A/600V/GTR/6U
6DI50B-050 254 2003+ FUJI 50A/500V/GTR/6U
6DI50C-050 100 2003+ FUJI 50A/500V/GTR/6U
6DI50M-050 256 2003+ FUJI 50A/500V/GTR/6U
6DI50M-120 317 2003+ FUJI 50A/1200V/GTR/6U
6DI50MA-050 257 2003+ FUJI 50A/500V/GTR/6U
6DI50MB-050 200 2003+ FUJI 50A/500V/GTR/6U
6DI50Z-120 318 2003+ FUJI 50A/1200V/GTR/6U
6DI75A-050 258 2003+ FUJI 75A/500V/GTR/6U
6DI75MA-050 260 2003+ FUJI 75A/500V/GTR/6U
6DI75MB-050 250 2003+ FUJI 75A/500V/GTR/6U
6MB100L-060ELX 50 2003+ FUJI 100A/600V/IGBT/6U
6MBI100F-060 149 2003+ FUJI 100A/600V/IGBT/6U
6MBI100FA-060 150 2003+ FUJI 100A/600V/IGBT/6U
6MBI100FC-060 100 2003+ FUJI 100A/600V/IGBT/6U
6MBI100J-060 50 2003+ FUJI 100A/600V/IGBT/6U
6MBI100L-060 118 2003+ FUJI 100A/600V/IGBT/6U
6MBI100NA-060 100 2003+ FUJI 100A/600V/IGBT/6U
6MBI100NA-060A 100 2003+ FUJI 100A/600V/IGBT/6U
6MBI100S-120 100 2003+ FUJI 100A/1200V/IGBT/6U
6MBI100S-140 45 2003+ FUJI 100A/1400V/IGBT/6U
6MBI100SA-120 67 2003+ FUJI 100A/1200V/IGBT/6U

6MBI100SA-120B 65 2003+ FUJI 100A/1200V/IGBT/6U
6MBI100U2B-060 100 2003+ FUJI 100A/600V/IGBT/6U
6MBI100U4B-120 30 2003+ FUJI 100A/1200V/IGBT/6U
6MBI100U4B-170 31 2003+ FUJI 100A/1700V/IGBT/6U
6MBI100UB-120 100 2003+ FUJI 100A/1200V/IGBT/6U
6MBI100UC-120 30 2003+ FUJI 100A/1200V/IGBT/6U
6MBI10F-060 140 2003+ FUJI 10A/600V/IGBT/6U
6MBI10GS-060 50 2003+ FUJI 10A/600V/IGBT/6U
6MBI10L-060 112 2003+ FUJI 10A/600V/IGBT/6U
6MBI10S-120 30 2003+ FUJI 10A/1200V/IGBT/6U
6MBI150FB-060 151 2003+ FUJI 150A/600V/IGBT/6U
6MBI150U-170 45 2003+ FUJI 150A/1700V/IGBT/6U
6MBI150U2B-060 50 2003+ FUJI 150A/600V/IGBT/6U
6MBI150U4B-120 32 2003+ FUJI 150A/1200V/IGBT/6U
6MBI150U4B-170 33 2003+ FUJI 150A/1700V/IGBT/6U
6MBI150UB-120 55 2003+ FUJI 150A/1200V/IGBT/6U
6MBI15F-120 161 2003+ FUJI 15A/1200V/IGBT/6U
6MBI15GS-060 55 2003+ FUJI 15A/600V/IGBT/6U
6MBI15L-060 113 2003+ FUJI 15A/600V/IGBT/6U
6MBI15L-120 128 2003+ FUJI 15A/1200V/IGBT/6U
6MBI15LS-060 115 2003+ FUJI 15A/600V/IGBT/6U
6MBI15S-120 100 2003+ FUJI 15A/1200V/IGBT/6U
6MBI200FA-060 66 2003+ FUJI 200A/600V/IGBT/6U
6MBI200FB-060 152 2003+ FUJI 200A/600V/IGBT/6U
6MBI200FC-060 67 2003+ FUJI 200A/600V/IGBT/6U
6MBI20F-060 59 2003+ FUJI 20A/600V/IGBT/6U
6MBI20GS-060 60 2003+ FUJI 20A/600V/IGBT/6U
6MBI20L-060 114 2003+ FUJI 20A/600V/IGBT/6U
6MBI225U-120 56 2003+ FUJI 225A/1200V/IGBT/6U
6MBI225U-170 60 2003+ FUJI 225A/1700V/IGBT/6U
6MBI225U4-120 34 2003+ FUJI 225A/1200V/IGBT/6U
6MBI225U4-170 35 2003+ FUJI 225A/1700V/IGBT/6U
6MBI25F-120 162 2003+ FUJI 25A/1200V/IGBT/6U
6MBI25GS-060 60 2003+ FUJI 25A/600V/IGBT/6U
6MBI25LB-120 131 2003+ FUJI 25A/1200V/IGBT/6U
6MBI25S-120 40 2003+ FUJI 25A/1200V/IGBT/6U
6MBI300U-120 50 2003+ FUJI 300A/1200V/IGBT/6U
6MBI300U-170 40 2003+ FUJI 300A/1700V/IGBT/6U
6MBI300U4-120 36 2003+ FUJI 300A/1200V/IGBT/6U
6MBI300U4-170 37 2003+ FUJI 300A/1700V/IGBT/6U
6MBI30F-060 143 2003+ FUJI 30A/600V/IGBT/6U
6MBI30FA-060 144 2003+ FUJI 30A/600V/IGBT/6U
6MBI30L-060 116 2003+ FUJI 30A/600V/IGBT/6U
6MBI35S-120 62 2003+ FUJI 35A/1200V/IGBT/6U
6MBI35S-140 50 2003+ FUJI 35A/1400V/IGBT/6U
6MBI40SS-060 40 2003+ FUJI 40A/600V/IGBT/6U
6MBI450U-120 50 2003+ FUJI 450A/1200V/IGBT/6U
6MBI450U-170 50 2003+ FUJI 450A/1700V/IGBT/6U
6MBI450U4-120 38 2003+ FUJI 450A/1200V/IGBT/6U
6MBI450U4-170 39 2003+ FUJI 450A/1700V/IGBT/6U
6MBI50F-060 145 2003+ FUJI 50A/600V/IGBT/6U
6MBI50F-120 163 2003+ FUJI 50A/1200V/IGBT/6U
6MBI50FA-060 146 2003+ FUJI 50A/600V/IGBT/6U
6MBI50J-120 50 2003+ FUJI 50A/1200V/IGBT/6U

6MBI50L-060 50 2003+ FUJI 50A/600V/IGBT/6U
6MBI50L-120 130 2003+ FUJI 50A/1200V/IGBT/6U
6MBI50S-120 63 2003+ FUJI 50A/1200V/IGBT/6U
6MBI50S-140 50 2003+ FUJI 50A/1400V/IGBT/6U
6MBI50U4A-120 40 2003+ FUJI 50A/1200V/IGBT/6U
6MBI50UA-120 80 2003+ FUJI 50A/1200V/IGBT/6U
6MBI75F-060 147 2003+ FUJI 75A/600V/IGBT/6U
6MBI75FA-060 148 2003+ FUJI 75A/600V/IGBT/6U
6MBI75L-060 117 2003+ FUJI 75A/600V/IGBT/6U
6MBI75NA-060 100 2003+ FUJI 100A/600V/IGBT/6U
6MBI75S-120 64 2003+ FUJI 75A/1200V/IGBT/6U
6MBI75S-140 50 2003+ FUJI 75A/1400V/IGBT/6U
6MBI75U2A-060 60 2003+ FUJI 75A/600V/IGBT/6U
6MBI75U4A-120 41 2003+ FUJI 75A/1200V/IGBT/6U
6MBI75U4B-120 42 2003+ FUJI 75A/1200V/IGBT/6U
6MBI75UA-120 50 2003+ FUJI 75A/1200V/IGBT/6U
6MBI75UB-120 55 2003+ FUJI 75A/1200V/IGBT/6U
6MBI75UC-120 60 2003+ FUJI 75A/1200V/IGBT/6U
6MBI8F-120 160 2003+ FUJI 8A/1200V/IGBT/6U
6MBI8L-120 127 2003+ FUJI 8A/1200V/IGBT/6U
6MBP100JA120 50 2003+ FUJI 100A/1200V/IPM/6U
6MBP100JB060 158 2003+ FUJI 100A/600V/IPM/6U
6MBP100KC060 150 2003+ FUJI 100A/600V/IPM/6U
6MBP100RA060 129 2003+ FUJI 100A/600V/IPM/6U
6MBP100RA120 142 2003+ FUJI 100A/1200V/IPM/6U
6MBP100RD060 100 2003+ FUJI 100A/600V/IPM/6U
6MBP100RH060 79 2003+ FUJI 100A/600V/IPM/6U
6MBP100RT060 83 2003+ FUJI 100/600V/IPM/6U
6MBP100RTB060 100 2003+ FUJI 100A/600V/IPM/6U
6MBP100RTJ060 43 2003+ FUJI 100A/600V/IPM/6U
6MBP100TEA060 46 2003+ FUJI 100A/600V/IPM/6U
6MBP150JA060 50 2003+ FUJI 150A/600V/IPM/6U
6MBP150JB060 159 2003+ FUJI 150A/600V/IPM/6U
6MBP150KA060 50 2003+ FUJI 150A/600V/IPM/6U
6MBP150RA060 130 2003+ FUJI 150A/600V/IPM/6U
6MBP150RA120 143 2003+ FUJI 150A/1200V/IPM/6U
6MBP150RS120 100 2003+ FUJI 150A/1200V/IPM/6U
6MBP150RTB060 150 2003+ FUJI 150A/600V/IPM/6U
6MBP150RTJ060 44 2003+ FUJI 150A/600V/IPM/6U
6MBP150RTS120 100 2003+ FUJI 150A/1200V/IPM/6U
6MBP150TEA060 47 2003+ FUJI 150A/600V/IPM/6U
6MBP15RH060 124 2003+ FUJI 15A/600V/IPM/6U
6MBP15RY060 121 2003+ FUJI 15A/600V/IPM/6U
6MBP160RT060 82 2003+ FUJI 160A/600V/IPM/6U
6MBP160RTA060 100 2003+ FUJI 160A/600V/IPM/6U
6MBP200JA060 50 2003+ FUJI 200A/600V/IPM/6U
6MBP200JB060 160 2003+ FUJI 200A/600V/IPM/6U
6MBP200KA060 50 2003+ FUJI 200A/600V/IPM/6U
6MBP200RA060 131 2003+ FUJI 200A/600V/IPM/6U
6MBP200RS060 100 2003+ FUJI 200A/600V/IPM/6U
6MBP200RTS060 50 2003+ FUJI 200A/600V/IPM/6U
6MBP20JB060 74 2003+ FUJI 20A/600V/IPM/6U
6MBP20RH060 400 2003+ FUJI 20A/600V/IPM/6U
6MBP20RTA060 250 2003+ FUJI 20A/600V/IPM/6U

6MBP20RY060 122 2003+ FUJI 20A/600V/IPM/6U
6MBP25NA120 100 2003+ FUJI 25A/1200V/IPM/6U
6MBP25RA120 139 2003+ FUJI 25A/1200V/IPM/6U
6MBP25RJ120 34 2003+ FUJI 25A/1200V/IPM/6U
6MBP25TEA120 48 2003+ FUJI 25A/1200V/IPM/6U
6MBP300JA060 50 2003+ FUJI 300A/600V/IPM/6U
6MBP300JB060 161 2003+ FUJI 300A/600V/IPM/6U
6MBP300KA060 50 2003+ FUJI 300A/600V/IPM/6U
6MBP300RA060 132 2003+ FUJI 300A/600V/IPM/6U
6MBP300RS060 25 2003+ FUJI 300A/600V/IPM/6U
6MBP300RTS060 55 2003+ FUJI 300A/600V/IPM/6U
6MBP30RH060 126 2003+ FUJI 30A/600V/IPM/6U
6MBP30RTA060 50 2003+ FUJI 30A/600V/IPM/6U
6MBP30RY060 123 2003+ FUJI 30A/600V/IPM/6U
6MBP50JB060 156 2003+ FUJI 50A/600V/IPM/6U
6MBP50NA060 250 2003+ FUJI 50A/600V/IPM/6U
6MBP50RA060 127 2003+ FUJI 50A/600V/IPM/6U
6MBP50RA120 140 2003+ FUJI 50A/1200V/IPM/6U
6MBP50RH060 84 2003+ FUJI 50A/600V/IPM/6U
6MBP50RJ120 100 2003+ FUJI 50A/1200V/IPM/6U
6MBP50RTA060 92 2003+ FUJI 50A/600V/IPM/6U
6MBP50RTB060 200 2003+ FUJI 50A/600V/IPM/6U
6MBP50RTJ060 45 2003+ FUJI 50A/600V/IPM/6U
6MBP50TEA120 49 2003+ FUJI 50A/1200V/IPM/6U
6MBP75JA120 50 2003+ FUJI 75A/1200V/IPM/6U
6MBP75JB060 157 2003+ FUJI 75A/600V/IPM/6U
6MBP75NA-060 50 2003+ FUJI 75A/600V/IPM/6U
6MBP75RA120 141 2003+ FUJI 75A/1200V/IPM/6U
6MBP75RAA120 25 2003+ FUJI 75A/1200V/IPM/6U
6MBP75RF060 78 2003+ FUJI 75A/600V/IPM/6U
6MBP75RH060 85 2003+ FUJI 75A/600V/IPM/6U
6MBP75RJ120 100 2003+ FUJI 75A/1200V/IPM/6U
6MBP75RS060 77 2003+ FUJI 75A/600V/IPM/6U
6MBP75RTB060 200 2003+ FUJI 75A/600V/IPM/6U
6MBP75TEA060 51 2003+ FUJI 75A/600V/IPM/6U
6MBP75TEA120 50 2003+ FUJI 75A/1200V/IPM/6U
6R1TI30Y-080 56 2003+ FUJI 30A/800V/SCR+DIODE/6U
6R6D10A-050BHX 159 2003+ FUJI 10A/500V/IPM/6U
6R6D10A-120BHX 156 2003+ FUJI 10A/1200V/IPM/6U
6R6D15A-050BHX 50 2003+ FUJI 15A/500V/GTR/6U
6R6D15A-120BHX 157 2003+ FUJI 15A/1200V/IPM/6U
6R6D20A-050BHX 159 2003+ FUJI 20A/500V/IPM/6U
6R6D25A-120BHX 100 2003+ FUJI 25A/1200V/GTR/6U
6R6D30A-050BHX 160 2003+ FUJI 30A/500V/IPM/6U
6R6D50A-050BHX 50 2003+ FUJI 50A/500V/GTR/6U
6RI100A-080 100 2003+ FUJI 100A/800V/DIODE/6U
6RI100E-060 341 2003+ FUJI 100A/600V/DIODE/6U
6RI100G-120 343 2003+ FUJI 100A/1200V/DIODE/6U
6RI100G-120B 100 2003+ FUJI 100A/1200V/DIODE/6U
6RI150E-060 345 2003+ FUJI 150A/600V/DIODE/6U
6RI150E-080 346 2003+ FUJI 150A/800V/DIODE/6U
6RI30B-060 100 2003+ FUJI 30A/600V/DIODE/6U
6RI30E-060 331 2003+ FUJI 30A/600V/DIODE/6U
6RI30FE-080 100 2003+ FUJI 30A/800V/DIODE/6U

6RI30G-120 333 2003+ FUJI 30A/1200V/DIODE/6U
6RI30G-160 334 2003+ FUJI 30A/1600V/DIODE/6U
6RI50A-060 100 2003+ FUJI 50A/600V/DIODE/6U
6RI50E-060 335 2003+ FUJI 50A/600V/DIODE/6U
6RI50E-080 336 2003+ FUJI 50A/800V/DIODE/6U
6RI75E-060 337 2003+ FUJI 75A/600V/DIODE/6U
6RI75G-120B 100 2003+ FUJI 75A/1200V/DIODE/6U
7D100A-050EHR 40 2003+ FUJI 100A/500V/GTR/7U
7D100D-050EHR 40 2003+ FUJI 100A/500V/GTR/7U
7D150A-050EHR 45 2003+ FUJI 150A/500V/GTR/7U
7D30D-050EHR 97 2003+ FUJI 30A/500V/GTR/7U
7D50A-050EHR 50 2003+ FUJI 50A/500V/GTR/7U
7D50D-050EHR 55 2003+ FUJI 50A/500V/GTR/7U
7D50D-050EJR 101 2003+ FUJI 50A/500V/GTR/7U
7D75A-050EHR 50 2003+ FUJI 75A/500V/GTR/7U
7D75A-050EJR 54 2003+ FUJI 75A/500V/GTR/7U
7D75D-050EJR 102 2003+ FUJI 75A/500V/GTR/7U
7MBI100N-060 191 2003+ FUJI 100A/600V/IGBT/7U
7MBI100SB060 50 2003+ FUJI 100A/600V/IGBT/7U
7MBI150SA-060B 50 2003+ FUJI 150A/600V/IGBT/7U
7MBI40N-120 192 2003+ FUJI 40A/1200V/IGBT/7U
7MBI50N-120 193 2003+ FUJI 50A/1200V/IGBT/7U
7MBI75N-060 190 2003+ FUJI 75A/600V/IGBT/7U
7MBI75SA-120 100 2003+ FUJI 75A/1200V/IGBT/7U
7MBP100JB060 151 2003+ FUJI 100A/600V/IPM/7U
7MBP100KB060 100 2003+ FUJI 100A/600V/IPM/7U
7MBP100NA-060 50 2003+ FUJI 100A/600V/IPM/7U
7MBP100RA060 135 2003+ FUJI 100A/600V/IPM/7U
7MBP100RA120 147 2003+ FUJI 100A/1200V/IPM/7U
7MBP100RTB060 150 2003+ FUJI 100A/600V/IPM/7U
7MBP100TEA060 52 2003+ FUJI 100A/600V/IPM/6U
7MBP150JB060 152 2003+ FUJI 150A/600V/IPM/7U
7MBP150KA060 89 2003+ FUJI 150A/600V/IPM/7U
7MBP150NA-060 50 2003+ FUJI 150A/600V/IPM/7U
7MBP150RA120 148 2003+ FUJI 150A/1200V/IPM/7U
7MBP150RTB060 150 2003+ FUJI 150A/600V/IPM/7U
7MBP150TEA060 53 2003+ FUJI 150A/600V/IPM/6U
7MBP200JB060 153 2003+ FUJI 200A/600V/IPM/7U
7MBP200KA060 130 2003+ FUJI 200A/600V/IPM/7U
7MBP200RA060 137 2003+ FUJI 200A/600V/IPM/7U
7MBP25RA120 144 2003+ FUJI 25A/1200V/IPM/7U
7MBP25RJ120 45 2003+ FUJI 25A/1200V/IPM/7U
7MBP25TEA120 54 2003+ FUJI 25A/1200V/IPM/7U
7MBP300JB060 154 2003+ FUJI 300A/600V/IPM/7U
7MBP300RA060 138 2003+ FUJI 300A/600V/IPM/7U
7MBP50NA060 83 2003+ FUJI 50A/600V/IPM/7U
7MBP50RA060 133 2003+ FUJI 50A/600V/IPM/7U
7MBP50RA120 145 2003+ FUJI 50A/1200V/IPM/7U
7MBP50RJ120 40 2003+ FUJI 50A/1200V/IPM/7U
7MBP50RTB060 200 2003+ FUJI 50A/600V/IPM/7U
7MBP50TEA060 55 2003+ FUJI 50A/600V/IPM/7U
7MBP50TEA120 56 2003+ FUJI 50A/1200V/IPM/7U
7MBP75NA060 50 2003+ FUJI 75A/600V/IPM/7U
7MBP75RA060 134 2003+ FUJI 75A/600V/IPM/7U

7MBP75RA120 146 2003+ FUJI 75A/1200V/IPM/7U
7MBP75RJ120 45 2003+ FUJI 75A/1200V/IPM/7U
7MBP75RTB060 200 2003+ FUJI 75A/600V/IPM/7U
7MBP75SD-060 50 2003+ FUJI 75A/600V/IPM/7U
7MBP75TEA060 57 2003+ FUJI 75A/600V/IPM/7U
7MBP75TEA120 58 2003+ FUJI 75A/1200V/IPM/7U
7MBP80RT060 87 2003+ FUJI 80A/600V/IPM/7U
7MBP80RTA060 120 2003+ FUJI 80A/600V/IPM/7U
7MBR100SA060 58 2003+ FUJI 100A/600V/PIM/7U
7MBR100SB060 109 2003+ FUJI 100A/600V/PIM/7U
7MBR100SD060 107 2003+ FUJI 100A/600V/PIM/7U
7MBR100U2B060 100 2003+ FUJI 100A/600V/PIM/7U
7MBR100U4B120 120 2003+ FUJI 100A/1200V/PIM/7U
7MBR100UB120 50 2003+ FUJI 100A/1200V/PIM/7U
7MBR10NF120 196 2003+ FUJI 10A/1200V/PIM/7U
7MBR10SA120 105 2003+ FUJI 10A/1200V/PIM/7U
7MBR10SA140 50 2003+ FUJI 10A/1400V/PIM/7U
7MBR10UF120 121 2003+ FUJI 10A/1200V/PIM/7U
7MBR15NE120 201 2003+ FUJI 15A/1200V/PIM/7U
7MBR15NF120 197 2003+ FUJI 15A/1200V/PIM/7U
7MBR15SA120 30 2003+ FUJI 15A/1200V/IPM/7U
7MBR15SA140 50 2003+ FUJI 15A/1400V/PIM/7U
7MBR15SC120 55 2003+ FUJI 15A/1200V/PIM/7U
7MBR15UF060 122 2003+ FUJI 15A/600V/PIM/7U
7MBR20SC060 45 2003+ FUJI 20A/600V/PIM/7U
7MBR20UF060 123 2003+ FUJI 20A/600V/PIM/7U
7MBR25NE120 202 2003+ FUJI 25A/1200V/PIM/7U
7MBR25NF120 198 2003+ FUJI 25A/1200V/PIM/7U
7MBR25SA120 103 2003+ FUJI 25A/1200V/PIM/7U
7MBR25SA140 50 2003+ FUJI 25A/1400V/PIM/7U
7MBR25SC120 55 2003+ FUJI 25A/1200V/PIM/7U
7MBR25UA120 50 2003+ FUJI 25A/1200V/PIM/7U
7MBR30JC060 100 2003+ FUJI 30A/600V/PIM/7U
7MBR30NE060 199 2003+ FUJI 30A/600V/PIM/7U
7MBR30NF060 194 2003+ FUJI 30A/600V/PIM/7U
7MBR30SA060 35 2003+ FUJI 30A/600V/PIM/7U
7MBR30SC060 56 2003+ FUJI 30A/600V/PIM/7U
7MBR30U2A060 50 2003+ FUJI 30A/600V/PIM/7U
7MBR30UF060 125 2003+ FUJI 30A/600V/PIM/7U
7MBR35SB120 102 2003+ FUJI 35A/1200V/PIM/7U
7MBR35SB140 60 2003+ FUJI 35A/1400V/PIM/7U
7MBR35SD120 50 2003+ FUJI 35A/1200V/IPM/7U
7MBR35UA120 55 2003+ FUJI 35A/1200V/PIM/7U
7MBR35UB120 55 2003+ FUJI 35A/1200V/PIM/7U
7MBR35UH120 30 2003+ FUJI 35A/1200V/PIM/7U
7MBR50JC060 200 2003+ FUJI 50A/600V/PIM/7U
7MBR50NE060 200 2003+ FUJI 50A/600V/PIM/7U
7MBR50NF-060 195 2003+ FUJI 50A/600V/PIM/7U
7MBR50SA060 56 2003+ FUJI 50A/600V/PIM/7U
7MBR50SB060 50 2003+ FUJI 50A/600V/PIM/7U
7MBR50SB120 40 2003+ FUJI 50A/1200V/PIM/7U
7MBR50U2A060 56 2003+ FUJI 50A/600V/PIM/7U
7MBR50UA120 35 2003+ FUJI 50A/1200V/PIM/7U
7MBR50UB120 35 2003+ FUJI 50A/1200V/PIM/7U

7MBR50UH120 50 2003+ FUJI 50A/1200V/PIM/7U
7MBR75SA060 57 2003+ FUJI 75A/600V/PIM/7U
7MBR75SB060 45 2003+ FUJI 75A/600V/PIM/7U
7MBR75SD060 25 2003+ FUJI 75A/600V/IPM/7U
7MBR75U2B060 35 2003+ FUJI 75A/600V/PIM/7U
7MBR75U4B120 126 2003+ FUJI 75A/1200V/PIM/7U
7MBR75UB120 30 2003+ FUJI 75A/1200V/PIM/7U
82D01171A-90LPBT 100 00+ FUJI BGA
82D04172-65LPBT 100 02+ FUJI BGA
84VD22183EE-90 300 00+ FUJI BGA
84VD22184A-10 100 03+ FUJI BGA
84VD22193A-10 100 03+ FUJI BGA
84VD22194A-10 100 00+ FUJI BGA
84VD22194EE-90 613 00+ FUJI BGA
84VD22283EA-90 300 01+ FUJI BGA
84VD22387EJ-90 100 01+ FUJI BGA
84VD23481FJ-70 100 02+ FUJI BGA
84VD23483EJ-90 300 01+ FUJI BGA
A50L-0001-0096 200 2003+ FUJI 75A/500V/GTR/2U
A50L-0001-0096/A 200 2003+ FUJI 75A/600V/GTR/2U
A50L-0001-0109 200 2003+ FUJI 120A/600V/GTR/2U
A50L-0001-0116 200 2003+ FUJI 200A/600V/GTR/1U
A50L-0001-0118 200 2003+ FUJI 75A/500V/GTR/2U
A50L-0001-0125 200 2003+ FUJI 150A/600V/GTR/6U
A50L-0001-0125-A 200 2003+ FUJI 50A/600V/GTR/6U
A50L-0001-0126 200 2003+ FUJI 50A/600V/GTR/1U
A50L-0001-0126-B 200 2003+ FUJI 50A/600V/GTR/1U
A50L-0001-0135 200 2003+ FUJI 300A/1200V/GTR/1U
A50L-0001-0171 200 2003+ FUJI 15A/500V/GTR/1U
A50L-0001-0175 200 2003+ FUJI 120A/600V/GTR/6U
A50L-0001-0175/M 200 2003+ FUJI 120A/600V/GTR/6U
A50L-0001-0178 200 2003+ FUJI 85A/600V/GTR/6U
A50L-0001-0179/15A 200 2003+ FUJI 15A/600V/GTR/1U
A50L-0001-0179/30A 200 2003+ FUJI 30A/600V/GTR/1U
A50L-0001-0201 200 2003+ FUJI 150A/600V/GTR/2U
A50L-0001-0216 200 2003+ FUJI 75A/600V/GTR/6U
A50L-0001-0221 200 2003+ FUJI 150A/600V/IGBT/6U
A50L-0001-0222 200 2003+ FUJI 200A/600V/IGBT/6U
A50L-0001-0230 200 2003+ FUJI 60A/600V/IGBT/6U
A50L-0001-0232 200 2003+ FUJI 30A/800V/DIODE/6U
A50L-0001-0259?200 2003+ FUJI 600A/600V/IGBT/1U
A50L-0001-0259?200 2003+ FUJI 600A/600V/IGBT/1U
A50L-0001-0259/A 200 2003+ FUJI 300A/600V/IGBT/2U
A50L-0001-0259-S 200 2003+ FUJI 300A/600V/IGBT/2U
A50L-0001-0260 45 2003+ FUJI 200A/600V/IGBT/2U
A50L-0001-0260/N 200 2003+ FUJI 200A/600V/IGBT/2U
A50L-0001-0260-S 200 2003+ FUJI 200A/600V/IGBT/2U
A50L-0001-0261/N 200 2003+ FUJI 150A/600V/IGBT/2U
A50L-0001-0261-S 200 2003+ FUJI 150A/600V/IGBT/2U
A50L-0001-0266-N 200 2003+ FUJI 50A/600V/IPM/7U
A50L-0001-0267-N 200 2003+ FUJI 75A/600V/IPM/7U
A50L-0001-0274-RA 200 2003+ FUJI 150A/600V/IPM/7U
A50L-0001-0274-RAS 200 2003+ FUJI 150A/600V/IPM/7U
A50L-0001-0275-S 200 2003+ FUJI 100A/600V/IPM/6U

A50L-0001-0284-L 200 2003+ FUJI 400A/600V/IGBT/2U
A50L-0001-0284-S 200 2003+ FUJI 400A/600V/IGBT/2U
A50L-0001-0291-L 200 2003+ FUJI 100A/600V/IPM/6U
A50L-0001-0295-NL 200 2003+ FUJI 600A/600V/IGBT/1U
A50L-0001-0295-PS 200 2003+ FUJI 600A/600V/IGBT/1U
A50L-0001-0299-P 200 2003+ FUJI 400A/1200V/IGBT/1U
A50L-0001-0301 200 2003+ FUJI 150A/600V/IGBT/2U
A50L-0001-0301-L 200 2003+ FUJI 150A/600V/IGBT/2U
A50L-0001-0302 200 2003+ FUJI 200A/600V/IGBT/2U
A50L-0001-0303 200 2003+ FUJI 300A/600V/IGBT/2U
A50L-0001-0304-S 200 2003+ FUJI 50A/600V/IPM/6U
A50L-0001-0305 200 2003+ FUJI 75A/600V/IPM/6U
A50L-0001-0305-S 200 2003+ FUJI 75A/600V/IPM/6U
A50L-0001-0306 200 2003+ FUJI 150A/600V/IPM/6U
A50L-0001-0320 200 2003+ FUJI 400A/600V/IGBT/2U
A50L-0001-0324 200 2003+ FUJI 75A/1200V/IPM/7U
A50L-0001-0326 200 2003+ FUJI 20A/600V/IPM/6U
A50L-0001-0327 200 2003+ FUJI 50A/600V/IPM/6U
A50L-0001-0328 200 2003+ FUJI 50A/600V/IPM/7U
A50L-0001-0330 200 2003+ FUJI 80A/600V/IPM/7U
A50L-0001-0332 200 2003+ FUJI 160A/600V/IPM/6U
A50L-0001-0333 200 2003+ FUJI 150A/600V/IPM/7U
A50L-0001-0335 200 2003+ FUJI 100A/600V/IPM/6U
A50L-0001-0336 200 2003+ FUJI 150A/600V/IPM/6U
A50L-0001-0337 200 2003+ FUJI 200A/600V/IGBT/2U
A50L-0001-0338 200 2003+ FUJI 300A/600V/IGBT/2U
A50L-0001-0340 200 2003+ FUJI 400A/600V/IGBT/2U
A50L-0001-0342 200 2003+ FUJI 200A/600V/IGBT/2U
A50L-0001-0343 200 2003+ FUJI 300A/600V/IGBT/2U
A50L-0001-0344 200 2003+ FUJI 400A/600V/IGBT/2U
A50L-5000-0017 200 2003+ FUJI 50A/400V/SCR/6U
A50L-5000-0025 200 2003+ FUJI 25A/400V/SCR/6U
B92-02 1000 04+ FUJI TO-220
C023M-15 100 05+ FUJI TO3P
C65-004 100 04+ FUJI TO-3P
C82-004 5000 03+ FUJI N/A
C92-02 1000 04+ FUJI TO-220
C92M-02 1000 03+ FUJI N/A
CR2L-100 100 2003+ FUJI 100A/250VAC
CR2L-125 100 2003+ FUJI 125A/250VAC
CR2L-150 100 2003+ FUJI 150A/250VAC
CR2L-175 100 2003+ FUJI 175A/250VAC
CR2L-200 100 2003+ FUJI 200A/250VAC
CR2L-225 100 2003+ FUJI 225A/250VAC
CR2L-260 100 2003+ FUJI 250A/260VAC
CR2L-30 100 2003+ FUJI 30A/250VAC
CR2L-300 100 2003+ FUJI 300A/250VAC
CR2L-325 100 2003+ FUJI 325A/250VAC
CR2L-350 100 2003+ FUJI 350A/250VAC
CR2L-400 100 2003+ FUJI 400A/250VAC
CR2L-450 100 2003+ FUJI 450A/250VAC
CR2L-50 100 2003+ FUJI 50A/250VAC
CR2L-75 100 2003+ FUJI 75A/250VAC
CR2LS-10 100 2003+ FUJI 10A/250VAC

CR2LS-100 100 2003+ FUJI 100A/250VAC
CR2LS-20 100 2003+ FUJI 20A/250VAC
CR2LS-30 100 2003+ FUJI 30A/250VAC
CR2LS-50 100 2003+ FUJI 50A/250VAC
CR2LS-75 100 2003+ FUJI 75A/250VAC
CR6L-100 100 2003+ FUJI 100A/600VAC
CR6L-150 100 2003+ FUJI 150A/600VAC
CR6L-20 100 2003+ FUJI 20A/600VAC
CR6L-200 100 2003+ FUJI 200A/600VAC
CR6L-250 100 2003+ FUJI 250A/600VAC
CR6L-30 100 2003+ FUJI 30A/600VAC
CR6L-300 100 2003+ FUJI 300A/600VAC
CR6L-350 100 2003+ FUJI 350A/600VAC
CR6L-400 100 2003+ FUJI 400A/600VAC
CR6L-50 100 2003+ FUJI 50A/600VAC
CR6L-500 100 2003+ FUJI 500A/600VAC
CR6L-600 100 2003+ FUJI 600A/600VAC
CR6L-75 100 2003+ FUJI 75A/600VAC
CTU24S 1800 03+ FUJI N/A
D83-004 4000 03+ FUJI TO-3P
D83M-004 500 03+ FUJI TO-3P
D92-02 3000 03+ FUJI TO-3P
D92-03 1000 04+ FUJI TO-3P
E09-15 500 05+ FUJI TO3P
E83-004 5000 03+ FUJI TO-3P
EMTG07-04 500 2003+ FUJI 50A/400V/SCR/6U
ERC20M-06 500 05+ FUJI TO220F
ERC24M-06 1000 05+ FUJI TO220F
ESAB85-009 300 05+ FUJI TO220
ESAC92-02 1590 05+ FUJI TO220
ESAD83M-004R 300 00+ FUJI TO-3P
ESAD85-009 300 05+ FUJI TO3P
ESAD85M-009 580 05+ FUJI TO3PF
ESAD92-02 300 03+ FUJI TO-3P
ESAD92-03 300 03+ FUJI TO-3P
ET1257 150 2003+ FUJI 200A/1000V/GTR/1U
ET1266M 200 2003+ FUJI 200A/900V/GTR/1U
ET127 50 2003+ FUJI 100A/450V/GTR/1U
ET1275 120 2003+ FUJI 15A/700V/GTR/1U
ET188 54 2003+ FUJI 100A/300V/GTR/1U
ET277 55 2003+ FUJI 200A/200V/GTR/1U
ET468 1650 04+ FUJI SOT-263
ETF11-050 150 2003+ FUJI 10A/500V/GTR/1U
ETF81-050 100 2003+ FUJI 15A/500V/GTR/1U
ETG81-050A 209 2003+ FUJI 30A/500V/GTR/1U
ETK81-050 230 2003+ FUJI 50A/500V/GTR/1U
ETK81-060B 100 2003+ FUJI 50A/600V/GTR/1U
ETK85-050 211 2003+ FUJI 75A/500V/GTR/1U
ETL81-050 212 2003+ FUJI 100A/500V/GTR/1U
ETM36-030 205 2003+ FUJI 200A/300V/GTR/1U
ETN31-055 264 2003+ FUJI 200A/550V/GTR/1U
ETN35-030 206 2003+ FUJI 300A/300V/GTR/1U
ETN36-030 207 2003+ FUJI 300A/300V/GTR/1U
ETN81-055 265 2003+ FUJI 200A/550V/GTR/1U

ETN85-050 213 2003+ FUJI 300A/500V/GTR/1U
EV1234 130 2003+ FUJI 50A/1000V/GTR/2U
EV1255 200 2003+ FUJI 100A/1000V/GTR/2U
EV1274 100 2003+ FUJI 20A/1000V/GTR/2U
EV1277 273 2003+ FUJI 30A/1000V/GTR/2U
EVF31H-035 45 2003+ FUJI 20A/350V/GTR/6U
EVF31H-050 45 2003+ FUJI 15A/450V/GTR/6U
EVF31T-050A 45 2003+ FUJI 15A/450V/GTR/6U
EVF33T-040 103 2003+ FUJI 15A/400V/GTR/6U
EVG31-050A 214 2003+ FUJI 30A/500V/GTR/2U
EVK71-050 216 2003+ FUJI 75A/500V/GTR/2U
EVK71-055 200 2003+ FUJI 75A/550V/GTR/2U
EVK71-060 200 2003+ FUJI 75A/600V/GTR/2U
EVL31-055 266 2003+ FUJI 100A/550V/GTR/2U
EVL32-055 267 2003+ FUJI 120A/550V/GTR/2U
EVL32-060D 200 2003+ FUJI 120A/550V/GTR/2U
EVM31-050 217 2003+ FUJI 150A/500V/GTR/2U
EVM31-050A 400 2003+ FUJI 150A/500V/GTR/2U
EVM31-050B 300 2003+ FUJI 150A/500V/GTR/2U
EVM31-060 500 2003+ FUJI 150A/600V/GTR/2U
EVM32-050A 200 2003+ FUJI 120A/500V/GTR/2U
F5018 1200 05+ FUJI TO252
F5018-S-TB16R 4000 05+ FUJI SOT-252
F5019 2500 05+ FUJI TO263
F5019-S-TE24R 1050 05+ FUJI SOT-263
F5023 2005 05+ FUJI TO220
F5042-S-TB16R 4000 05+ FUJI SOT-252
F5043 2005 05+ FUJI TO263
FA5304 15000 00+ FUJI DIP-8
FSLC-S090S-163 400 05+ FUJI 3(0603)
IMBH50-060 100 05+ FUJI TO3PL
KKS926SZ 1300 05+ FUJI SOT-252
MB1511HPFV 1100 02+ FUJI TSSOP-20
MB3773P 100 06+PB FUJI DIP-8
MB621940UPF-G-BND 400 03+ FUJI QFP
MB7318Y-SK 600 03+ FUJI CDIP-24
MB87002 1170 03+ FUJI SOP-16
MB89363-PF-G-BND 100 03+ FUJI QFP
MBM29DL640E-90 300 01+ FUJI BGA
PM200CLS060 100 2003+ FUJI 200A/600V/IPM/6U
PM300CLS060 100 2003+ FUJI 300A/600V/IPM/6U
SC015-2-TE12RA 5600 05+ FUJI SMA
SC015-4-TE12RA 3900 05+ FUJI SMA-2
SC016-2-TE12 15000 05+ FUJI SMA
SC016-4-TE12RA 9300 05+ FUJI SMA-2
SC016-6-TE12RA 1500 05+ FUJI SMA
SC016-8-TE12RA 7000 05+ FUJI SMA-2
SC017-4-TE12 3000 05+ FUJI SMA
SC201-2-TE16RA 1900 05+ FUJI SMA-2
SC201-6-TE12RA 1500 05+ FUJI SMA
SC201-8-TE12RA 1200 05+PB FUJI SMA-2
SC311-4-TE12RA 1500 05+ FUJI SMA
SC321-2-TE12RA 130500 05+ FUJI SMA-2
SC802-04 14250 05+ FUJI SMA

SC802-04-TE12RA 5438 05+ FUJI SMA-2
SC802-06-TE12RA 6000 05+ FUJI SMA-2
SC802-09-TE12R 7500 05+ FUJI SMA
SC802-09-TE12RA 3800 05+ FUJI SMA-2
SC902-2 400 04+ FUJI SMA-2
SC902-2A-TE12RA 1700 05+ FUJI SMA-2
SC902-2-TE12R 9100 05+PB1100 FUJI SMA-2
SD833-04-TE12R 1500 05+ FUJI N/A
SD833-09-TE12R 2700 05+ FUJI SMA
SE014-TR12R 2250 05+ FUJI SOT-89
SE036-TE12R 2950 05+ FUJI SOT-89
SE059 1450 05+ FUJI SOT-89
SE059-TE12R 4000 05+ FUJI SOT-89
TS802C09-TE24R 1650 05+ FUJI SOT-263
TS805C04-TE24R 800 05+ FUJI TO263
TS808C06 500 05+ FUJI TO263
TS808C06-TE24R 800 02+ FUJI SOT-263
TS902C2-TE24R 850 05+ FUJI SOT-263
TS906C2 1000 05+ FUJI TO263
TS912S6 1000 05+ FUJI TO263
YG802C04R 1000 05+ FUJI TO-220
YG802C06 500 03+ FUJI TO-220
YG902C2 1500 03+ FUJI TO-220
YG902C2R 1500 05+ FUJI TO-220
YG902C3R 950 00+ FUJI TO-220F
MD36710XC4 498 9925 FUJIFILM QFP
MB86H20APMT-G-BND 3299 0535+ FUJISTU QFP
MB86H20APMT-G-BNDE1 10 06+ FUJISTU QFP
MB91F318APMT-G120 5691 2005 FUJISTU QFP
131926-00400 45 03+ FUJITSU TO-220
1D300A-030 35 N/A FUJITSU GTR
1D480A-055 60 N/A FUJITSU GTR
1D500A-030 30 N/A FUJITSU GTR
1D600A-030 20 N/A FUJITSU GTR
1DI150M-120 10 N/A FUJITSU GTR
1DI150N-120 15 N/A FUJITSU GTR
1DI15A-050 22 N/A FUJITSU GTR
1DI15A-060 50 N/A FUJITSU GTR
1DI200E-055 22 N/A FUJITSU GTR
1DI200H-055 45 N/A FUJITSU GTR
1DI200K-055 35 N/A FUJITSU GTR
1DI200MA-050 30 N/A FUJITSU GTR
1DI200Z-120 20 N/A FUJITSU GTR
1DI200ZN-120 18 N/A FUJITSU GTR
1DI200ZP-120 13 N/A FUJITSU GTR
1DI240A-055 19 N/A FUJITSU GTR
1DI240A-060 13 N/A FUJITSU GTR
1DI300A-030 2 N/A FUJITSU GTR
1DI300A-120 14 N/A FUJITSU GTR
1DI300B-120 8 N/A FUJITSU GTR
1DI300D-100 25 N/A FUJITSU GTR
1DI300M-120/140 21 N/A FUJITSU GTR
1DI300MN-050 31 N/A FUJITSU GTR
1DI300MP-050 20 N/A FUJITSU GTR

1DI300X-120 11 N/A FUJITSU GTR
1DI300Z-100 3 N/A FUJITSU GTR
1DI300Z-120 30 N/A FUJITSU GTR
1DI300ZA-100 18 N/A FUJITSU GTR
1DI300ZN-120 15 N/A FUJITSU GTR
1DI300ZP-120 22 N/A FUJITSU GTR
1DI30A-055 45 N/A FUJITSU GTR
1DI30A-060 91 N/A FUJITSU GTR
1DI30F-050 20 N/A FUJITSU GTR
1DI30F-100 15 N/A FUJITSU GTR
1DI30MA-050 40 N/A FUJITSU GTR
1DI400A-120 38 N/A FUJITSU GTR
1DI400D-100 104 N/A FUJITSU GTR
1DI400L-120 55 N/A FUJITSU GTR
1DI400N-120 12 N/A FUJITSU GTR
1DI400X-120 18 N/A FUJITSU GTR
1DI480A-055 50 N/A FUJITSU GTR
1DI50A-055 10 N/A FUJITSU GTR
1DI50A-060 2 N/A FUJITSU GTR
1DI50MA-050 20 N/A FUJITSU GTR
1DI75H-100 15 N/A FUJITSU GTR
1F60A-120F 97 N/A FUJITSU FAST RECOVERY DIODE MODULE
1F60A-120R 40 N/A FUJITSU FAST RECOVERY DIODE MODULE
1FI250B-060 20 N/A FUJITSU FAST RECOVERY DIODE MODULE
1M240S-050 100 N/A FUJITSU FET
1MBI200L-120 15 N/A FUJITSU IGBT
1MBI200N-120 16 N/A FUJITSU IGBT
1MBI300F-060 25 N/A FUJITSU IGBT
1MBI300L-060 50 N/A FUJITSU IGBT
1MBI300N-120 35 N/A FUJITSU IGBT
1MBI300NN-060 50 N/A FUJITSU IGBT
1MBI30L-060 60 N/A FUJITSU IGBT
1MBI400L-060 10 N/A FUJITSU IGBT
1MBI400L-120 14 N/A FUJITSU IGBT
1MBI400N-120 20 N/A FUJITSU IGBT
1MBI400NA-120 18 N/A FUJITSU IGBT
1MBI400NN-120 25 N/A FUJITSU IGBT
1MBI400NP-120 35 N/A FUJITSU IGBT
1MBI400S-120 38 N/A FUJITSU IGBT
1MBI50L-060 50 N/A FUJITSU IGBT
1MBI600LN-060 12 N/A FUJITSU IGBT
1MBI600LP-060 17 N/A FUJITSU IGBT
1MBI600NN-060 24 N/A FUJITSU IGBT
1MBI600NP-060 45 N/A FUJITSU IGBT
1MBI600S-120 18 N/A FUJITSU IGBT
1MBI75L-060 50 N/A FUJITSU IGBT
1SI100A-100 30 N/A FUJITSU GTR
1SI50A-050 30 N/A FUJITSU GTR
1SI50A-100 45 N/A FUJITSU GTR
2DI100A-120 20 N/A FUJITSU GTR
2DI100D-050C 24 N/A FUJITSU GTR
2DI100M-120 22 N/A FUJITSU GTR
2DI100MA-050 23 N/A FUJITSU GTR
2DI100MA-120 25 N/A FUJITSU GTR

2DI100Z-120 15 N/A FUJITSU GTR
2DI150A-120 14 N/A FUJITSU GTR
2DI150B-120 15 N/A FUJITSU GTR
2DI150D-050 20 N/A FUJITSU GTR
2DI150G-100 10 N/A FUJITSU GTR
2DI150M-050 14 N/A FUJITSU GTR
2DI150MA-050 30 N/A FUJITSU GTR
2DI150MA-120 35 N/A FUJITSU GTR
2DI150MB-050 28 N/A FUJITSU GTR
2DI150Z-100 23 N/A FUJITSU GTR
2DI150Z-120 16 N/A FUJITSU GTR
2DI150ZA-100 8 N/A FUJITSU GTR
2DI200A-050 30 N/A FUJITSU GTR
2DI200M-050 35 N/A FUJITSU GTR
2DI200MB-050 28 N/A FUJITSU GTR
2DI200MC-050 55 N/A FUJITSU GTR
2DI240A-055 50 N/A FUJITSU GTR
2DI300A-050 35 N/A FUJITSU GTR
2DI300M-050 19 N/A FUJITSU GTR
2DI30A-050 35 N/A FUJITSU GTR
2DI30A-120 30 N/A FUJITSU GTR
2DI30D-050 25 N/A FUJITSU GTR
2DI30M-050 14 N/A FUJITSU GTR
2DI30Z-100 15 N/A FUJITSU GTR
2DI50A-120 15 N/A FUJITSU GTR
2DI50D-050A 26 N/A FUJITSU GTR
2DI50D-055 10 N/A FUJITSU GTR
2DI50D-100 35 N/A FUJITSU GTR
2DI50M-050 38 N/A FUJITSU GTR
2DI50M-120 20 N/A FUJITSU GTR
2DI50Z-100 15 N/A FUJITSU GTR
2DI50Z-120 25 N/A FUJITSU GTR
2DI75A-100 10 N/A FUJITSU GTR
2DI75A-120 15 N/A FUJITSU GTR
2DI75D-050A 19 N/A FUJITSU GTR
2DI75D-050B 20 N/A FUJITSU GTR
2DI75D-100 8 N/A FUJITSU GTR
2DI75M-050 29 N/A FUJITSU GTR
2DI75M-120 7 N/A FUJITSU GTR
2DI75MA-120 8 N/A FUJITSU GTR
2DI75S-050A 13 N/A FUJITSU GTR
2DI75Z-100 28 N/A FUJITSU GTR
2DI75ZA-100 17 N/A FUJITSU GTR
2FI100A-030N 34 N/A FUJITSU FAST RECOVERY DIODE MODULE
2FI100A-060 20 N/A FUJITSU FAST RECOVERY DIODE MODULE
2FI100A-060C 100 N/A FUJITSU FAST RECOVERY DIODE MODULE
2FI100A-060D 25 N/A FUJITSU FAST RECOVERY DIODE MODULE
2FI100F-060D 23 N/A FUJITSU FAST RECOVERY DIODE MODULE
2FI150F-060D 75 N/A FUJITSU FAST RECOVERY DIODE MODULE
2FI200A-060D 16 N/A FUJITSU FAST RECOVERY DIODE MODULE
2FI200A-060N 14 N/A FUJITSU FAST RECOVERY DIODE MODULE
2FI300A-060 35 N/A FUJITSU FAST RECOVERY DIODE MODULE
2FI50A-060D 25 N/A FUJITSU FAST RECOVERY DIODE MODULE
2MBI100J-060 35 N/A FUJITSU IGBT

2MBI100L-060 25 N/A FUJITSU IGBT
2MBI100N-060 260 N/A FUJITSU IGBT
2MBI100N-120 15 N/A FUJITSU IGBT
2MBI100NB-120 11 N/A FUJITSU IGBT
2MBI100NC-120 10 N/A FUJITSU IGBT
2MBI100NE-120 4 N/A FUJITSU IGBT
2MBI100PC-140 5 N/A FUJITSU IGBT
2MBI100SC-120 4 N/A FUJITSU IGBT
2MBI100Z-060 35 N/A FUJITSU IGBT
2MBI150-060 25 N/A FUJITSU IGBT
2MBI150FC-140 6 N/A FUJITSU IGBT
2MBI150J-060 55 N/A FUJITSU IGBT
2MBI150J-120 50 N/A FUJITSU IGBT
2MBI150KB-060 60 N/A FUJITSU IGBT
2MBI150L-060 21 N/A FUJITSU IGBT
2MBI150L-120 15 N/A FUJITSU IGBT
2MBI150N-060 46 N/A FUJITSU IGBT
2MBI150N-120 38 N/A FUJITSU IGBT
2MBI150NB-120 30 N/A FUJITSU IGBT
2MBI150NC-060 54 N/A FUJITSU IGBT
2MBI150NR-060 10 N/A FUJITSU IGBT
2MBI150NT-120A 15 N/A FUJITSU IGBT
2MBI150PC-140 25 N/A FUJITSU IGBT
2MBI150SC-120 20 N/A FUJITSU IGBT
2MBI150SD-060 9 N/A FUJITSU IGBT
2MBI200F-060 10 N/A FUJITSU IGBT
2MBI200J-060 14 N/A FUJITSU IGBT
2MBI200K-060 13 N/A FUJITSU IGBT
2MBI200KB-060 30 N/A FUJITSU IGBT
2MBI200L-060 20 N/A FUJITSU IGBT
2MBI200L-120 40 N/A FUJITSU IGBT
2MBI200N-060 150 N/A FUJITSU IGBT
2MBI200N-120 6 N/A FUJITSU IGBT
2MBI200NB-120 38 N/A FUJITSU IGBT
2MBI200NK-060 15 N/A FUJITSU IGBT
2MBI200NR-060 10 N/A FUJITSU IGBT
2MBI200SK-060 16 N/A FUJITSU IGBT
2MBI200TA-060 15 N/A FUJITSU IGBT
2MBI200TC-060 9 N/A FUJITSU IGBT
2MBI25-120 45 N/A FUJITSU IGBT
2MBI25L-120 50 N/A FUJITSU IGBT
2MBI300J-060 18 N/A FUJITSU IGBT
2MBI300K-060 12 N/A FUJITSU IGBT
2MBI300L-060 23 N/A FUJITSU IGBT
2MBI300LB-060 49 N/A FUJITSU IGBT
2MBI300N-060 45 N/A FUJITSU IGBT
2MBI300N-120 35 N/A FUJITSU IGBT
2MBI300NB-060 350 N/A FUJITSU IGBT
2MBI300NK-060 50 N/A FUJITSU IGBT
2MBI300NR-060 60 N/A FUJITSU IGBT
2MBI300P-140 38 N/A FUJITSU IGBT
2MBI300S-120B 28 N/A FUJITSU IGBT
2MBI300TA-060 40 N/A FUJITSU IGBT
2MBI300TC-060 50 N/A FUJITSU IGBT

2MBI400K-060 50 N/A FUJITSU IGBT
2MBI400N-060 50 N/A FUJITSU IGBT
2MBI400NK-060 15 N/A FUJITSU IGBT
2MBI400NT-060 45 N/A FUJITSU IGBT
2MBI400SK-060 50 N/A FUJITSU IGBT
2MBI400TB-060 60 N/A FUJITSU IGBT
2MBI400TC-060 35 N/A FUJITSU IGBT
2MBI50F-060 65 N/A FUJITSU IGBT
2MBI50F-120 40 N/A FUJITSU IGBT
2MBI50L-060 100 N/A FUJITSU IGBT
2MBI50L-120 50 N/A FUJITSU IGBT
2MBI50N-060 42 N/A FUJITSU IGBT
2MBI50N-120 40 N/A FUJITSU IGBT
2MBI600NT-060 50 N/A FUJITSU IGBT
2MBI75J-060 40 N/A FUJITSU IGBT
2MBI75L-060 93 N/A FUJITSU IGBT
2MBI75L-120 25 N/A FUJITSU IGBT
2MBI75N-060 183 N/A FUJITSU IGBT
2MBI75N-120 55 N/A FUJITSU IGBT
2MBI75P-140 60 N/A FUJITSU IGBT
2MBI75S-120 20 N/A FUJITSU IGBT
2MI100F-025 40 N/A FUJITSU FET
2MI100F-050A 46 N/A FUJITSU FET
2MI50F-050 278 N/A FUJITSU FET
2MI50S-050 50 N/A FUJITSU FET
2R6D15A-050AJV 100 N/A FUJITSU MODULE
2R6D15S-050AJV 50 N/A FUJITSU MODULE
2R6D20A-050AJV 55 N/A FUJITSU MODULE
2R6D20S-050AJV 65 N/A FUJITSU MODULE
2RI100A-060 60 N/A FUJITSU POWER DIODE MODULE
2RI100E-060 50 N/A FUJITSU POWER DIODE MODULE
2RI100E-080 42 N/A FUJITSU POWER DIODE MODULE
2RI100G-160 60 N/A FUJITSU POWER DIODE MODULE
2RI60E-080 100 N/A FUJITSU POWER DIODE MODULE
2RI60F-080 55 N/A FUJITSU POWER DIODE MODULE
2RI60G-160 80 N/A FUJITSU POWER DIODE MODULE
4R1TI20Y-080 100 N/A FUJITSU MODULE
4R3TI20Y-080 63 N/A FUJITSU MODULE
4R3TI30Y-080 85 N/A FUJITSU MODULE
4R3TI60Y-080 68 N/A FUJITSU MODULE
4R6D10A-050BHX 65 N/A FUJITSU MODULE
4R6D20S-040AJX 75 N/A FUJITSU MODULE
6D100A-050ELXS 100 N/A FUJITSU GTR
6D50A-120ELX 100 N/A FUJITSU GTR
6D75A-050ELX 100 N/A FUJITSU GTR
6DI100A-050 150 N/A FUJITSU POWER TRANSISTOR MODULE
6DI100A-050ELX 150 N/A FUJITSU POWER TRANSISTOR MODULE
6DI100AH-050 100 N/A FUJITSU POWER TRANSISTOR MODULE
6DI100M-050 120 N/A FUJITSU POWER TRANSISTOR MODULE
6DI10A-050 25 N/A FUJITSU POWER TRANSISTOR MODULE
6DI10MS-050 36 N/A FUJITSU POWER TRANSISTOR MODULE
6DI120A-060 100 N/A FUJITSU POWER TRANSISTOR MODULE
6DI120C-060 75 N/A FUJITSU POWER TRANSISTOR MODULE
6DI120D-060 50 N/A FUJITSU POWER TRANSISTOR MODULE

6DI150A-060 30 N/A FUJITSU POWER TRANSISTOR MODULE
6DI15A-050 270 N/A FUJITSU POWER TRANSISTOR MODULE
6DI15A-120 55 N/A FUJITSU POWER TRANSISTOR MODULE
6DI15MS-050 35 N/A FUJITSU POWER TRANSISTOR MODULE
6DI15S-050 326 N/A FUJITSU POWER TRANSISTOR MODULE
6DI15S-050C 210 N/A FUJITSU POWER TRANSISTOR MODULE
6DI15S-050D 300 N/A FUJITSU POWER TRANSISTOR MODULE
6DI15Z-050 100 N/A FUJITSU POWER TRANSISTOR MODULE
6DI20A-040 78 N/A FUJITSU POWER TRANSISTOR MODULE
6DI20A-050 76 N/A FUJITSU POWER TRANSISTOR MODULE
6DI20B-050 50 N/A FUJITSU POWER TRANSISTOR MODULE
6DI20C-040 60 N/A FUJITSU POWER TRANSISTOR MODULE
6DI20C-050 70 N/A FUJITSU POWER TRANSISTOR MODULE
6DI20D-040 86 N/A FUJITSU POWER TRANSISTOR MODULE
6DI20MS-050 400 N/A FUJITSU POWER TRANSISTOR MODULE
6DI20S-050A 60 N/A FUJITSU POWER TRANSISTOR MODULE
6DI20S-050D 230 N/A FUJITSU POWER TRANSISTOR MODULE
6DI30A-050 56 N/A FUJITSU POWER TRANSISTOR MODULE
6DI30A-120 4 N/A FUJITSU POWER TRANSISTOR MODULE
6DI30AH-050 2 N/A FUJITSU POWER TRANSISTOR MODULE
6DI30B-050 56 N/A FUJITSU POWER TRANSISTOR MODULE
6DI30B-050A 100 N/A FUJITSU POWER TRANSISTOR MODULE
6DI30M-050 75 N/A FUJITSU POWER TRANSISTOR MODULE
6DI30M-120 40 N/A FUJITSU POWER TRANSISTOR MODULE
6DI30MA-050 14 N/A FUJITSU POWER TRANSISTOR MODULE
6DI30MS-050A 54 N/A FUJITSU POWER TRANSISTOR MODULE
6DI30Z-100 45 N/A FUJITSU POWER TRANSISTOR MODULE
6DI50A-050 38 N/A FUJITSU POWER TRANSISTOR MODULE
6DI50A-060 171 N/A FUJITSU POWER TRANSISTOR MODULE
6DI50AH-050 65 N/A FUJITSU POWER TRANSISTOR MODULE
6DI50B-050 50 N/A FUJITSU POWER TRANSISTOR MODULE
6DI50C-050 40 N/A FUJITSU POWER TRANSISTOR MODULE
6DI50M-050 58 N/A FUJITSU POWER TRANSISTOR MODULE
6DI50MA-050 63 N/A FUJITSU POWER TRANSISTOR MODULE
6DI75A-050 18 N/A FUJITSU POWER TRANSISTOR MODULE
6DI75AH-050 35 N/A FUJITSU POWER TRANSISTOR MODULE
6DI75M-050 50 N/A FUJITSU POWER TRANSISTOR MODULE
6DI75MA-050 65 N/A FUJITSU POWER TRANSISTOR MODULE
6DI75MB-050 54 N/A FUJITSU POWER TRANSISTOR MODULE
6DI85A-060 51 N/A FUJITSU POWER TRANSISTOR MODULE
6MBI100F-060 50 N/A FUJITSU IGBT
6MBI100FA-060 75 N/A FUJITSU IGBT
6MBI100FC-060 45 N/A FUJITSU IGBT
6MBI100J-060 30 N/A FUJITSU IGBT
6MBI100J-060B 35 N/A FUJITSU IGBT
6MBI100L-060 50 N/A FUJITSU IGBT
6MBI100S-060 65 N/A FUJITSU IGBT
6MBI100S-120 35 N/A FUJITSU IGBT
6MBI100SA-120B 46 N/A FUJITSU IGBT
6MBI100UB-120 5 N/A FUJITSU IGBT
6MBI10L-060 38 N/A FUJITSU IGBT
6MBI10S-120 55 N/A FUJITSU IGBT
6MBI15-060 100 N/A FUJITSU IGBT
6MBI150FA-060 40 N/A FUJITSU IGBT

6MBI150FB-060 30 N/A FUJITSU IGBT
6MBI150SA-060B 50 N/A FUJITSU IGBT
6MBI15-120 35 N/A FUJITSU IGBT
6MBI15F-120 54 N/A FUJITSU IGBT
6MBI15GS-060 100 N/A FUJITSU IGBT
6MBI15L-060 70 N/A FUJITSU IGBT
6MBI15L-120 28 N/A FUJITSU IGBT
6MBI15LS-060 35 N/A FUJITSU IGBT
6MBI15S-120 25 N/A FUJITSU IGBT
6MBI200FA-060 335 N/A FUJITSU IGBT
6MBI20F-060 63 N/A FUJITSU IGBT
6MBI20GS-060 250 N/A FUJITSU IGBT
6MBI20JB-060 20 N/A FUJITSU IGBT
6MBI20L-060 50 N/A FUJITSU IGBT
6MBI250SW-120 25 N/A FUJITSU IGBT
6MBI25GS-060 1000 N/A FUJITSU IGBT
6MBI25J-120 50 N/A FUJITSU IGBT
6MBI25L-120 170 N/A FUJITSU IGBT
6MBI25LB-120 10 N/A FUJITSU IGBT
6MBI30FA-060 58 N/A FUJITSU IGBT
6MBI30L-060 50 N/A FUJITSU IGBT
6MBI30L-120 40 N/A FUJITSU IGBT
6MBI35S-120 30 N/A FUJITSU IGBT
6MBI40SS-060 390 N/A FUJITSU IGBT
6MBI50F-120 35 N/A FUJITSU IGBT
6MBI50J-060 46 N/A FUJITSU IGBT
6MBI50J-120 25 N/A FUJITSU IGBT
6MBI50L-060 73 N/A FUJITSU IGBT
6MBI50L-120 22 N/A FUJITSU IGBT
6MBI50S-120 35 N/A FUJITSU IGBT
6MBI60FA-060 143 N/A FUJITSU IGBT
6MBI75F-060 45 N/A FUJITSU IGBT
6MBI75FA-060 64 N/A FUJITSU IGBT
6MBI75J-060 64 N/A FUJITSU IGBT
6MBI75L-060 35 N/A FUJITSU IGBT
6MBI75S-120 36 N/A FUJITSU IGBT
6MBI8L-120 11 N/A FUJITSU IGBT
6MBP100JA060 10 N/A FUJITSU IPM
6MBP100JA120 2 N/A FUJITSU IPM
6MBP100KB060 9 N/A FUJITSU IPM
6MBP100KC060 47 N/A FUJITSU IPM
6MBP100RA060 37 N/A FUJITSU IPM
6MBP100RD060 57 N/A FUJITSU IPM
6MBP100RH060 36 N/A FUJITSU IPM
6MBP100RS060 68 N/A FUJITSU IPM
6MBP100RTA060 69 N/A FUJITSU IPM
6MBP100RTC060 56 N/A FUJITSU IPM
6MBP150JA060 48 N/A FUJITSU IPM
6MBP150NA060 37 N/A FUJITSU IPM
6MBP150RA060 37 N/A FUJITSU IPM
6MBP150RD060 26 N/A FUJITSU IPM
6MBP150RS060 39 N/A FUJITSU IPM
6MBP150RTC060 36 N/A FUJITSU IPM
6MBP15JB060 130 N/A FUJITSU IPM

6MBP15RH060 80 N/A FUJITSU IPM
6MBP15RHA060 80 N/A FUJITSU IPM
6MBP15RZ-060 200 N/A FUJITSU IPM
6MBP160RTA060 30 N/A FUJITSU IPM
6MBP200KA060 46 N/A FUJITSU IPM
6MBP200RA060 47 N/A FUJITSU IPM
6MBP200RS060 37 N/A FUJITSU IPM
6MBP20JB060 61 N/A FUJITSU IPM
6MBP20JB060-3 49 N/A FUJITSU IPM
6MBP20JE060 45 N/A FUJITSU IPM
6MBP20RH060 23 N/A FUJITSU IPM
6MBP20RTA060 151 N/A FUJITSU IPM
6MBP20RY060 21 N/A FUJITSU IPM
6MBP25NA120 38 N/A FUJITSU IPM
6MBP25TEA120 35 N/A FUJITSU IPM
6MBP300KA060 68 N/A FUJITSU IPM
6MBP300RA060 36 N/A FUJITSU IPM
6MBP300RD060 54 N/A FUJITSU IPM
6MBP30JE060 25 N/A FUJITSU IPM
6MBP30RH060 62 N/A FUJITSU IPM
6MBP30RTB060 19 N/A FUJITSU IPM
6MBP30RY060 110 N/A FUJITSU IPM
6MBP50NA060 26 N/A FUJITSU IPM
6MBP50RA060 38 N/A FUJITSU IPM
6MBP50RH060 30 N/A FUJITSU IPM
6MBP50RS060 69 N/A FUJITSU IPM
6MBP50RS120 36 N/A FUJITSU IPM
6MBP50RTA060 60 N/A FUJITSU IPM
6MBP50TEA060 58 N/A FUJITSU IPM
6MBP75JA120 37 N/A FUJITSU IPM
6MBP75NA060 69 N/A FUJITSU IPM
6MBP75RA060 47 N/A FUJITSU IPM